

Title:	Carrousel Rotation Interval	ID:	
		0024	
Date in:	Response:	Model:	Author:
2003-04-16	2003-04-16	-	CMa

Q:

During normal operation, the robotic carrousel rotates periodically.
At what time interval does this occur ?

A:

On you system every 60sec. The timer value is in DM23 and it can be changed by
"WR M23 xx"